



21E 36' to 44'

21W 36' to 48'



All fingers east and west 40'
 Except 1E, 2E & 1W 30'. AB 20'. AA 16'
 Dock 8' W, Fingers 4' W, 96 Pilings

B Dock



B2 16' to 20'

B1 30' to 37'

Boat sizes 27' to 33'

Boat size 30' to 40'

Fingers 20'

Fingers 30'

Dock 8' W, Fingers 4' W, 36 Pilings

Between
Fingers

C DOCK

Between
Fingers

12' 4"



32 31

12' 2"



24'



30 29

24' 5"



25' 2"



28 27

24' 7"



24' 6"



26 25

25' 1"



26' 3"



24 23

25' 6"



22' 10"



22 21

24' 8"



24' 5"



20 19

23' 9"



22'



18 17

20' 9"



23'



16 15

23' 9"



14 13

12 11

10 9

8 7

6 5

4 3

2 1

CD CC

CB CA

CA 22' to 25'

Boat Size 24' to 30'

Boat Size 22' to 26'

Fingers 20'

Fingers 20'

Dock 8' W, Fingers 4' W, 22 Pilings

Between
Fingers

Between
Fingers

D DOCK

9' 6"

9' 6"



48 47

18' 8"

18' 8"



46 45

44 43

18' 9"

18' 9"



42 41

40 39

18' 8"

18' 8"



38 37

36 35

18' 9"

18' 9"



34 33

32 31

18' 9"

18' 9"



30 29

28 27

18' 9"

18' 9"



26 25

24 23

18' 9"

18' 9"



22 21

20 19

18' 9"

18' 9"



18 17

16 15

18' 9"

18' 9"



14 13

12 11

19' 2"

19' 2"



10 9

8 7

22' 10"

22' 10"



6 5

4 3

2 1

D2 16' to 19'
Boat size 16' to 22'
Fingers 16'

Boat size 18' to 23'
Fingers 18'

Dock 6' W, Finger 30" W, 26 Pilings

Between
Fingers

E DOCK

Between
Fingers

7' 4"

52 51

7' 4"



17'

50 49

16' 9"



16' 8"

48 47

16' 10"



15' 1"

46 45

15' 6"



17' 1"

44 43

16' 8"



18' 7"

42 41

18' 6"



16' 11"

40 39

17' 1"



16' 11"

38 37

16' 11"



17'

36 35

16' 10"



16' 11"

34 33

17'



16' 10"

32 31



16' 10"



16' 9"

30 29

16' 9"



8' 6"

28 27



8' 4"



8' 4"

26 25

8' 1"



Open

24 23

22 21

20 19

18 17

16 15

14 13

12 11

10 9

8 7

6 5

4 3

2 1

Boat Size 12' to 18'

Boat Size 12; to 18'

Except E, 9, 11, 13 (12' -20')


Fingers east side = 14'

Fingers west side = 16'

Dock 6' W, Fingers 30" W, 30 Pilings


All fingers are 30'

All channel side slips are 28' to 34'



Osprey Nest





Legend Sail Boats, Power boats, Slip sizes

